

For maintenance with minimum effort please note the following instructions:

Good doormats at the entrances keep away most of the sand and dirt and reduce the need for cleaning and care. Please clean doormats and dust control mats regularly.

Loose dirt and dust should be regularly swept with a soft broom or vacuum-cleaned with a special parquet adapter.

Water on the parquet leads to swelling and eventually appearance of joints. Therefore please wipe up spilled liquids immediately. Flower pots and mats should have felt pads underneath them, allowing air to circulate.

Dry indoor air and high temperatures lead to appearance of joints, cracks and deformation, especially in the winter or if you have an underfloor heating system. For an ideal indoor climate, the humidity should be between 50 - 60 %. It should never drop down to 35 %. During the winter, we recommend to use suitable humidifiers. Underfloor heating may not be covered with thick carpets or mattresses (heat accumulation).

Furniture feet should be fitted with felt pads.

## **Underlay mats**

Suitable underlay mats underneath chairs with casters prevent damages and premature wear of the surface. Pads and casters should be cleaned regularly and replaced in time.

Sand, dry microfibers, acid or alkaline substances, solvents, stiletto heels, metal and metal abrasion may corrode the surface and lead to pressure marks, scratches or discoloration.

## **Cleaning and Care**

Several care products are suitable for initial care and maintenance cleaning:

Initial care (directly after installation) Please ask for detailed information

Maintenance Please ask for detailed information